

# *Inspired CORE* Air Purification System



QuickStart Guide



# CORE QUICKSTART GUIDE

## PACKAGE CONTENTS

- 1 - CORE Unit
- 1 - Hose
- 1 - Hose Connector
- 2 - Hose Clamps
- 2 - Key Sets

## WARNINGS & CAUTIONS



Directly viewing the lamp inside unit for an extended period may result in eye damage.



Turn off the unit when doing any maintenance.



Do not use your bare hands when replacing the UV Bulb as the oils on your hands can weaken it and shorten its life.



Each Ballast in the unit is tied to 2 Bulbs. When one bulb burns out the LED light on the Ballast will turn off. This will safely let you know it's time to change a Bulb.



Should one of your Ballast overheat, it will automatically turn itself off.

## INSTALLATION INSTRUCTIONS

1. Find the ideal location to mount CORE.
2. Connect CORE to the wall with the ideal screw you purchased separately.
3. Drill a Port in the area/container you want to be purified.
4. Attach the Hose Connector to the Port.
5. Run the Hose from CORE to the Area/Container and Clamp each side.
6. Connect the power.

Inspiredtecllc.com

